

Limited Lifetime Consumer Warranty

For a period of one calendar year from the date of purchase of this auto-security device, Directed Electronics, Inc. promises to the ORIGINAL PURCHASER to repair or replace (with a comparable reconditioned model), free of cost, any electronic control module which proves to be defective in workmanship or material under normal use, SO LONG AS THE SYSTEM WAS SOLD, INSTALLED, AND SERVICED BY A PROFESSIONAL AUTO INSTALLER, AND REMAINS IN THE CAR IN WHICH THE SYSTEM WAS ORIGINALLY INSTALLED. If warranty service is necessary you must have a clear copy of your sales receipt containing all of the information shown on the following page.

After the first calendar year, from the date of purchase of this auto-security device, Directed Electronics, Inc., promises to the ORIGINAL PURCHASER to repair or replace (with a comparable reconditioned model) any electronic control module which proves to be defective in workmanship or material under normal use **FOR A CHARGE OF \$45.00**, SO LONG AS THE SYSTEM WAS SOLD, INSTALLED, AND SERVICED BY A PRO-FESSIONAL AUTO INSTALLER, AND REMAINS IN THE CAR IN WHICH THE SYSTEM WAS ORIGINALLY INSTALLED. If warranty service is necessary you must have a clear copy of your sales receipt containing all of the information shown on the following page.

This warranty contains the entire agreement relating to warranty and supersedes all previous and contemporaneous representations or understandings, whether written or oral. IN ANY EVENT, DIRECTED ELECTRONICS, INC. IS NOT LIABLE FOR THE THEFT OF THE VEHICLE AND/OR ITS CONTENTS.

This warranty is void if the product has been damaged by accident, unreasonable use, neglect, improper service or other causes not arising out of defects in materials or construction. This warranty is nontransferable and does not apply to any unit that has been modified or used in a manner contrary to its intended purpose and does not cover batteries. The unit in question must be returned to the manufacturer, postage prepaid. This warranty <u>does not</u> cover labor costs for the removal, diagnosis, troubleshooting or reinstallation of the unit. For service on an out-of-warranty product a flat rate fee by model is charged. Contact your authorized dealer to obtain the service charge for your unit.

These systems are a deterrent against possible theft. Directed Electronics, Inc. is not offering a guarantee or insuring against the theft of the automobile or its contents and disclaims any liability for the theft of the vehicle and/or its contents. Directed Electronics does not authorize any person to create for it any other obligation or liability in connection with this security system.

TO THE MAXIMUM EXTENT ALLOWED BY LAW, ANY AND ALL WARRANTIES ARE EXCLUD-ED BY THE MANUFACTURER AND EACH ENTITY PARTICIPATING IN THE STREAM OF COM-MERCE THEREWITH. THIS EXCLUSION INCLUDES BUT IS NOT LIMITED TO THE EXCLU-SION OF ANY AND ALL WARRANTY OF MERCHANTABILITY AND/OR ANY AND ALL WAR-RANTY OF FITNESS FOR A PARTICULAR PURPOSE AND/OR ANY AND ALL WARRANTY OF NON-INFRINGEMENT OF PATENTS, IN THE UNITED STATES OF AMERICA AND/OR ABROAD. NEITHER THE MANUFACTURER OR ANY ENTITIES CONNECTED THEREWITH SHALL BE RESPONSIBLE OR LIABLE FOR ANY DAMAGES WHATSOEVER, INCLUDING BUT NOT LIMITED TO ANY CONSEQUENTIAL DAMAGES, INCIDENTAL DAMAGES, TOWING, REPAIR, REPLACEMENT, DAMAGES FOR LOSS OF TIME, LOSS OF EARNINGS, COMMERCIAL LOSS, LOSS OF ECONOMIC OPPORTUNITY AND THE LIKE. NOTWITHSTANDING THE ABOVE, MANUFACTURER DOES OFFER A LIMITED WARRANTY TO REPLACE OR REPAIR THE CONTROL MODULE AS DESCRIBED ABOVE. Some states do not allow limitations on how long an implied warranty will last or the exclusion or limitation of incidental or consequential damages. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

IMPORTANT NOTE:

This product warranty is automatically void if its date code or serial number is defaced, missing, or altered. This warranty will not be valid unless you have completed the warranty card and mailed it to Directed Electronics, Inc. within 10 days after purchase to the address listed on the warranty registration card.

Make sure you have all of the following information from your dealer:

A clear copy of the sales receipt, showing the following:

- Date of purchase
- Your full name and address
- Authorized dealer's company name and address
- Type of system installed
- Year, make, model and color of the automobile
- Automobile license number
- Vehicle identification number
- All security options installed on automobile
- Installation receipts

Table of Contents

Limited Lifetime Consumer Warrantyi
What is Included
Important Information
System Maintenance
Your Warranty
FCC/ID Notice
Caution
Transmitter Functions
Standard Configuration
Using Your System
Warning! Safety First
Locking
Unlocking
Ignition Controlled Door Locks
Remote Start
Short-Run/Turbo
Timer Mode
Valet® Take-Over
Programming Options
Glossary of Terms

What is Included

- The control module
- A 3-button transmitter
- A push-button programming switch
- Your warranty card
- A shut-down toggle switch

Important Information

Congratulations on the purchase of your remote start keyless entry system. This system has been designed to provide years of trouble-free operation. By carefully reading this owner's guide prior to using your system, you will maximize the use of this system and its features. Additional or replacement copies of this guide can be printed by accessing the Directed Electronics, Inc. internet website at www.directed.com.

System Maintenance

The system requires no specific maintenance. Your remote is powered by a miniature 3V lithium battery that lasts approximately one year under normal use. When the battery weakens, the LED on the remote will dim and operating range will be reduced.

Your Warranty

Your warranty card must be completely filled out and returned within 10 days of purchase. Your product warranty will not be honored if your warranty card is not returned. Make sure that you receive the warranty card from your dealer.

FCC/ID Notice

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

Caution

This product is designed for fuel injected, automatic transmission vehicles only. Use of this product in a standard transmission vehicle is dangerous and contrary the product's intended use.

Transmitter Functions

The receiver uses a computer-based learn routine to learn the transmitter buttons. This makes it possible to assign any specific transmitter button, or combination of buttons, to any receiver function. The transmitter initially comes programmed with the Standard Configuration, but may also be customized by an authorized dealer. Unless otherwise specified, the buttons used in all of the instructions in this manual correspond to a Standard Configuration transmitter.

Standard Configuration

Button 🛃 🖉

The door locking and unlocking functions are controlled by pressing \mathbb{Z}/\mathbb{Z}

Button AUX

The channel 2 output or trunk release is controlled by the AUX button.

Button 🗰

The remote start function of your system is controlled by pressing *****.

Buttons 🗟 🖉 + 🗛 🗛

When simultaneously pressed these buttons control the timer mode.

Buttons 🗟 🖉 + 🗰

When simultaneously pressed these buttons control the tubo/short run mode.



Warning! Safety First

The following safety warnings must be observed at all times:

- Due to the complexity of this system, installation of this product must only be performed by an authorized Directed Electronics, Inc. dealer.
- When properly installed, this system can start the vehicle via a command signal from the remote control transmitter. Therefore, never operate the system in an enclosed area or partially enclosed area without ventilation (such as a garage). When parking in an enclosed or partially enclosed area or when having the vehicle serviced, the remote start system must be disabled using the installed toggle switch. It is the user's sole responsibility to properly handle and keep out of reach from children all remote control transmitters to assure that the system does not unintentionally remote start the vehicle. THE USER MUST INSTALL A CARBON MONOXIDE DETECTOR IN OR ABOUT THE LIVING AREA ADJACENT TO THE VEHICLE. ALL DOORS LEADING FROM ADJACENT LIV-

ING AREAS TO THE ENCLOSED OR PARTIALLY ENCLOSED VEHICLE STORAGE AREA MUST AT ALL TIMES REMAIN CLOSED. These precautions are the sole responsibility of the user.

- Use of this product in a manner contrary to its intended mode of operation may result in property damage, personal injury, or death. (1) Never remotely start the vehicle with the vehicle in gear, and (2) Never remotely start the vehicle with the keys in the ignition. The user must also have the neutral safety feature of the vehicle periodically checked, wherein the vehicle must not remotely start while the car is in gear. This testing should be performed by an authorized Directed Electronics, Inc. dealer in accordance with the Safety Check outlined in the product installation guide. If the vehicle starts in gear, cease remote start operation immediately and consult with the authorized Directed Electronics, Inc.dealer to fix the problem.
- After the remote start module has been installed, contact your authorized dealer to have him or her test the remote start module by performing the Safety Check outlined in the product installation guide. If the vehicle starts when performing the Neutral Safety Shutdown Circuit test, the remote start unit has not been properly installed. The remote start module must be removed or the installer must properly reinstall the remote start system so that the vehicle does not start in gear. All installations must be performed by an authorized Directed Electronics dealer. OPERATION OF THE REMOTE START MOD-

ULE IF THE VEHICLE STARTS IN GEAR IS CONTRARY TO ITS INTENDED MODE OF OPERATION. OPERATING THE REMOTE START SYSTEM UNDER THESE CONDITIONS MAY RESULT IN PROPERTY DAMAGE OR PERSONAL INJURY. YOU MUST IMME-DIATELY CEASE THE USE OF THE UNIT AND SEEK THE ASSIS-TANCE OF AN AUTHORIZED DIRECTED ELECTRONICS, INC. DEALER TO REPAIR OR DISCONNECT THE INSTALLED REMOTE START MODULE. DIRECTED ELECTRONICS, INC.WILL NOT BE HELD RESPONSIBLE OR PAY FOR INSTALLATION OR REIN-STALLATION COSTS.


Locking

Pressing Δ/Δ° for one second will lock the doors. The parking lights will flash once to confirm that the doors are locked.

Unlocking

To unlock the doors press $\mathbb{A}/\mathbb{A}^{\circ}$ for one second. The parking lights will flash twice to confirm that the doors are unlocked.

Ignition Controlled Door Locks



If power door locks have been connected to your system, the vehicle's door will lock three seconds after the ignition has been turned on and unlock when the ignition is turned off.



NOTE: If the ignition is turned on while the vehicle is remote started the doors will not lock until the remote start shuts off. To avoid being locked out of the vehicle, do not turn the ignition on until you are ready to drive the vehicle.

Remote Start

This feature allows you to remotely start and run your vehicle for a programmable period of time. This makes it possible to warm up the engine, as well as adjust the interior temperature of the vehicle with the climate control system. If interior heating or cooling is desired, the climate controls must be preset, and the fan blower must be set to the desired level prior to remote starting the vehicle.

IMPORTANT! (1) Never remotely start the vehicle with the vehicle in gear, and (2) Never remotely start the vehicle with the key in the ignition.

To remote start the vehicle:

- 1. Press (*) on the transmitter twice within 3 seconds.
- 2. The parking lights will flash to confirm remote start operation.


3. Once the vehicle has started, it will run for the pre-programmed period of time (12, 24, or 60 minutes) or until a shutdown input is triggered.

When you are ready to drive the vehicle:

- Insert the ignition key and turn it to the ON (not the START) position.
- 2. Press the brake pedal.

NOTE: If the brake pedal is pressed before the key is in the ON position, the engine will shut down.





While the vehicle is running during remote start operation, the system will monitor the vehicle and will automatically shut down the engine if the system receives any of the following shut-down inputs:

- The brake pedal is pressed.
- The hood is opened.
- The shutdown toggle switch is put into the ON position.
- The pre-programmed run time has elapsed.
- The source button is pressed twice within 3 seconds.

Short-Run/Turbo

Short run turbo mode keeps the engine running after arriving at you destination for a programmable period of 1, 3, 5 or 10 minutes. This allows the system's timer to conveniently cool down the turbo after you have left the vehicle.

To activate:

- 1. Park the vehicle and set parking brake.
- 2. Remove your foot from the brake pedal and leave the engine running.
- 3. Press and release the same and A buttons at the same time.
- 4. The lights will flash to indicate the remote start has entered short run turbo mode.
- 5. Turn off the key, the engine will keep running.
- 6. Exit and secure the vehicle.
- 7. The engine will turn off after the programmed run time.

Timer Mode

By pressing the remote Δ / Δ and ΔUX buttons the parking lights will flash 4 times and then start the vehicle and run for the set duration. The remote start can be shut off by the transmitter by pressing the remote start button ΔUX and remain in timer mode, but if any other shut down zones or the ignition becomes active the timer mode will cancel.

- 1. Press Timer mode buttons.
- 2. The vehicle will confirm with 4 parking light flashes.
- 3. A 1-second delay will start.

4. The system will start the car and will run for the specified duration, unless shut down by the remote start button (*). If shut down with the remote start button (*) the system will remain in timer mode.

5. The system will start every 3 hours until canceled by the brake, hood, or neutral safety shut-down wires.

IMPORTANT! Timer Mode should be used only in open areas. Never start and run the vehicle in an enclosed space such as a garage or carport.

To exit timer mode, turn the ignition switch on any time the engine is running. The parking lights will flash 4 times, indicating timer mode has been exited.

Valet[®] Take-Over

The Valet[®] Take-Over feature allows the vehicle to remain running after the key has been removed from the ignition. This feature is useful for occasions when you wish to exit and lock the vehicle for short periods of time, but would like to leave the motor running and the climate controls on.

To perform Valet Take-Over:

- Before turning off the engine, press and release * twice within 2 seconds (or press and release the optional Momentary switch).
- Turn the ignition key to the OFF position. (The engine will stay running.)



3. The engine will run until the pre-programmed time elapses or a shut-down input is received. (See the previous Remote Start section for a complete list of shut-down inputs.)

NOTE: This feature will not work if the brake pedal is being pressed.

Programming Options

Programming options control your system's normal, operational set-up. Most options do not require additional parts, but some may require installation labor.

The following is a list of the programmable options, with the factory settings in **Bold**.

- 12, 24, or 60 minute run time. Your system can be programmed to allow the vehicle to run for 12, 24, or 60 minutes when remote started.
- Parking lights flashing or constant. Your system can be programmed to turn on the parking lights for the entire remote start operation.

Glossary of Terms

Control Unit: The "brain" of your system. Usually hidden underneath the dash area of the vehicle. It houses the microprocessor which monitors your vehicle and controls all the system functions.

Transmitter: A hand-held, remote control which operates the various functions of your system.

QUICK REFERENCE GUIDE:

To lock the doors using your remote

■ Pressing ▲/ for one second will lock the doors. The parking lights will flash once to confirm the doors are locked.

To unlock the doors using your remote

■ To unlock the doors, press ▲/ for one second. The parking lights will flash twice to confirm the doors are unlocked.

To remote start the vehicle

Press the solution twice within 3 seconds. The parking lights will flash to confirm remote start operation. Once the remote start has been activated, the vehicle will run for the preprogrammed period or until a shutdown input is triggered.

 $\boldsymbol{\chi}$

X

The company behind this system is Directed Electronics, Inc.

Since its inception, Directed Electronics, Inc. has had one purpose, to provide consumers with the finest vehicle security and car stereo products and accessories available. The recipient of more than 20 patents in the field of advanced electronic technology, Directed Electronics, Inc.is ISO 9001 registered.

Quality Directed Electronics products are sold and serviced throughout North America and around the world.

Call (800) 274-0200 for more information about our products and services.



DEI is an ISO 9001 registered company.

Directed Electronics, Inc. is committed to delivering on time, the best products we know how to provide, and to constantly work with our customers and vendors to improve our products, quality, delivery and customer friendly features.



ELECTRONICS, INC.

Directed Electronics, Inc. Vista, CA 92081 www.directed.com © 2003 Directed Electronics, Inc. - All rights reserved G561V 06-03